



ERGOMASTER

PRO control panel

Buttons							Pressing time	Action
S	1	2	3	4	+	-		
					*			going up
						*		going down
HEIGHT MEMORIZING								
*	*						Firstly click "S" then number	current height saved as 1
*		*						current height saved as 2
*			*					current height saved as 3
*				*				current height saved as 4
SETTING HEIGHT FROM MEMORY								
	*							desk goes to memory height 1
		*						desk goes to memory height 2
			*					desk goes to memory height 3
				*				desk goes to memory height 4
MANUAL REINITIALIZING/CALIBRATION/FACTORY SETTINGS								
*					*	*	min 4 sec	then PRESS [-] TO RESET
ANTICOLLISION SENSIVITY SETTING								
*	*						min 4 sec	low sensivity
*		*					min 4 sec	medium sensivity
*			*				min 4 sec	high sensivity
*				*			min 4 sec	anticollision OFF
CHANGING MEASURMENTS UNITS								
*	*					*	min 4 sec	swapping inches/centimetres
DISPLAY BRIGHTNESS								
	*				*	*	min 4 sec	brightness 1
		*			*	*	min 4 sec	brightness 2
			*		*	*	min 4 sec	brightness 3
				*	*	*	min 4 sec	brightness 4
TRAVEL LIMITS SETTINGS								
*					*		min 4 sec	current height saved as minimum travel limit
*						*	min 4 sec	current height saved as maximum travel limit
ONE TOUCH GO								
		*		*			min 4 sec	turn on/off ONE TOUCH GO
	*	*					min 4 sec	information about MP4
			*	*			min 4 sec	information about Power Supply
ERRORS								
ENGINE TEMPERATURE TOO HIGH								COOLING TIME
LOAD ON DESK TOO HIGH								DESK OVERLOAD
COLLISION DURING UPWARDS								UPPER ANTICOLLISION
COLLISION DURING DOWNWARDS								LOWER ANTICOLLISION